Your assembly instructions and user guide

for the Kiddicare.com

Sleigh Cot Bed

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

You will need these instructions after you have assembled the Sleigh Cot Bed.

Contents

1. Parts List	2
2. Assembly instructions	3
3. Choosing the mattress	4
4. Guide for safe use	5
5. Cleaning instructions	5
6. Maintenance	5

Kiddicare.com


Club Way Hampton Park Hampton Peterborough Cambridgeshire PE7 8JA


1. Parts List


All the parts you need to assemble the Sleigh Cot Bed are provided.

Before assembling the Sleigh Cot Bed check that you have all the parts listed below.

If any parts are missing please contact your retailer or phone 01952 461148.







Part Name	Qty	Part No	Part Name	Qty	Part No
1a & b – Cot Ends	2		4– Mattress Base	1	
2 – Cot Side (front)	1				
3 – Cot Side (rear)	1				

2. Assembly instructions

Tools required: Allen wrench (provided), Flat head screw driver.

Note: It is recommended that assembly and dismantling is carried out by two persons, one person to hold the parts in position the other to screw in the fixings.

WARNING. Keep young children away from the area you are using to assemble or dismantle the Sleigh Cot Bed. Some of the parts are heavy and could fall on the child. Some of the fixings are a choking hazard to young children.

WARNING Incorrect assembly or failure to follow these instructions could result in serious injury or death.

ATTACHING THE MATTRESS BASE TO THE COT ENDS


The mattress base has 2 mattress base height positions. We recommended that the lowest position is used as this is the safest. You must use the lowest position if the child is able to sit up.

Attach the Mattress base (4), to the Cot ends (1ab) at your chosen height, using the Long fixing bolts (C) and the Barrel nuts (B).

Using a screwdriver align the threaded hole of the barrel nut in the corner of the mattress base and insert the fixing bolt, through one of the mattress base support holes (depending on the chosen mattress height setting) in the end and into the drilled holes in the ends of the mattress base.


Use the Allen wrench (A) to screw the fixing bolts into the barrel nuts – DO NOT TIGHTEN.

Follow these steps for each corner of the mattress base – DO NOT TIGHTEN.



ATTACHING THE COT SIDES

Attach the COT SIDES (2) to the ends (1) using the Short fixing bolts (D) as shown. NOW TIGHTEN ALL OF THE BOLTS.



Attaching the cot sides

DISASSEMBLING THE COT FOR TRANSPORTATION OR STORAGE


Using the Allan wrench (A) loosen all the Fixing bolts. Start by removing the top fixing and work down. Remove the fixed side by unscrewing the top fixings, followed by the lower ones. Finally unscrew each of the base fixings. Store all parts not required safely, out of reach of children.

ATTACHING THE BED ENDS TO THE MATTRESS BASE

Remove the lower section of both ends (parts a and b), including the small panel as shown. The upper sections – A will be used for the bed end.

Attach the Mattress base (4) to one of the Cot ends (1), using the Fixing bolts (C) and the Barrel nuts (B) following the same steps you used to fix the mattress base to the cot ends. Attach the cot bed foot end (3) to the mattress base

NOW TIGHTEN ALL OF THE BOLTS.



3. Choosing the mattress

A mattress is not supplied with the Sleigh Cot Bed.

We recommend that you use a 140 cm by 69 cm mattress with the Sleigh Cot Bed.

Any mattress used with the Sleigh Cot Bed must have a length between 140 cm and 142 cm and a width between 68 cm and a width of 70 cm. Babies can become trapped in gaps between the cot sides and a mattress that is too small and may suffocate.

The thickness of the mattress when used in the cot must not be more than 100 mm. The maximum height of the mattress when the mattress base is in the raised position is indicated on the cot by a notch marked on the inside of each corner post. When the mattress base is in its lowest position the distance between the top of the mattress and the top of the cot side must not exceed 500 mm.

WARNING: Do not use more than one mattress in the cot. A child's head or torso may become trapped between the side of the cot and the mattress or they may become wedged between the mattresses.

4. Guide for safe use

The cot is suitable for children from birth. The cot should be used with the base set to the lowest position as soon as the baby is old enough to sit up. The child has outgrown the cot when it is able to climb out (approximately 18 months to two years of age). To prevent injury from falls the Sleigh Cot Bed should be converted to a bed for the child's use.

This child's bed is suitable for children who have outgrown a cot (approximately 18 months of age) up to the age of 4 years.

Babies can suffocate on soft bedding. Never use a pillow, comforter or padding in the cot.

To reduce the risk of SIDS, paediatricians recommend healthy babies be placed on their backs to sleep, unless otherwise advised by your doctor.

Children are likely to play, bounce, jump and climb on beds, the child's bed should not be placed too close to other furniture or windows, and should be placed either tight to any wall or have a gap of 300 mm between the wall and the side of the bed. It is strongly recommended that children are supervised and discouraged from jumping or climbing on the Sleigh Cot Bed.

WARNING: Do not place the Sleigh Cot Bed near heat sources. Be aware of the risk of

open fire and other sources of strong heat, such as electric bar fires, gas

fires, etc. in the vicinity of the cot.

WARNING: Do not leave anything in the cot or place the cot close to another product,

which could provide a foothold or present a danger of suffocation or

strangulation, e.g. strings, blind/curtain cords, etc.

WARNING: Do not use the Sleigh Cot Bed if any part is broken, torn or missing.

WARNING. Do not place this child's bed near windows and other furniture.

5. Cleaning instructions

The Sleigh Cot Bed may be cleaned by wiping with a damp cloth and drying with a soft clean cloth.

Do not use abrasives, bleach, alcohol or ammonia-based household polishes.

6. Maintenance

All assembly fittings should always be tightened properly and checked regularly and retightened as necessary. Loose fixings may snag a child's clothing or pinch fingers or flesh.

Spare or replacement parts can be obtained from Little Acorns by phoning 01952 461148. It is recommended that any additional parts are obtained from the manufacturer or distributor.

WARNING: Do not use the Sleigh Cot Bed if any part is broken torn or missing. Use

only spare or replacement parts approved by the manufacturer.

Conforms to BS 8509:2008+A1:2011 and EN716-1:2008+A1:2013