

HOT WATER BOTTLE

Directions for use:


When filling this hot water bottle, DO NOT USE BOILING WATER and fill to a maximum of two thirds capacity or less. Hold the bottle by the neck in an upright position and fill slowly to avoid hot water splashing back.

Expel air from the bottle by lowering it carefully onto a flat surface until water appears at the opening. Screw the stopper sufficiently tight to ensure that there is no leakage. Finger tight should be adequate.

Carefully insert the bottle into its cover ensuring that the fabric lies flat. When not in use, drain completely and keep with the stopper removed, in a cool, dry, dark place.

Prevent exposure to sunlight.

Do not place anything on top of the hot water bottle during storage.



Care and Safety advice:

Do not overfill as this might cause the bottle to burst. We advise customers that hot water bottles are not suitable for children under 36 months due to the risk of overheating.



Do not fill using water from the domestic hot water system as this can considerably shorten the life of the hot water bottle. Prevent contact with hot surfaces. Prevent contact with oil or grease. Check the bottle and stopper for wear and damage prior to use. Finally, make sure the funnel is empty. If there is a possibility that prolonged contact with the skin could occur, an adequate cover should be used to prevent burns. Under no circumstance should the hot water bottle be used as a cushion and be sat on.



Warnings:

Hot water bottles can cause burns. Avoid prolonged direct contact with the skin. Keep out of reach of children. Keep away from fire. Please retain these instructions for future reference. Stop using the product at the first sign of damage or weakness. Do not use hot water bottle with electric blanket. Please retain packaging for future reference.